

Components

Inside of the package you will find:

- 2 or 3 or 4 outer sensors
- CPU box with built in 90 db speaker for audio alerts, RS-232 connector for user changes via the LI user's software and update firmware via internet
- Power switch with built in LED indicator for ON/OFF and flashes upon action
- Function switch to change the mode of your LI anytime you wish(from normal behaviour to permanent parking mode)
- Installation accessories, mounting hardware, brackets, key-chain sensor installation bubble-level, zip-ties
- English User Manual